

DESCRIPTION



VAM85


24 V electromotive proportional actuator with feedback, valve stroke detection system and electrical fail-safe. Max stroke 6.3 mm.

Suitable for:

- all axial VANTEC PICV VA93VL, VA93L and VA93H
- all VANTEC Hydraulic KITVA813VL, VA81 3L and VA81 3H

Connection M30x1.5, adapted to PICV standards through specific adaptors(OA7010 or OA748X) included in the valves and kits packaging.

DIMENSIONS



TECHNICAL FEATURES

Type	Proportional	Actuating force	160N
Supply voltage	24V AC/DC +15% 50-60 Hz	Running time	8 sec/mm
Control signal	0(2)- 10VDC - 0(4)-20mA	Max fluid temperature	95°C
Feedback	0- 10VDC +5%	Max storage temperature	-20°/+ 65° (@)
Power consumption (acting)	2,5 VA / 1,5 W	Max ambient temperature	-0°/+ 50° (@)
Power consumption (charging)	5 VA /3 W	Degree of protection	IP54/III
Input impedance (voltage control)	> 100 Q	Weight	200 g
Input impedance (current control)	5000	Colour	White
Charging time	150 s	Connection cable	4 x 0.35 mm ²
Max stroke	6,3 mm - stroke detection	Cable length	1.5 m
		Noise level	<30 dB(A)

(@) non condensing

The 24 V electromotive actuator VAM85 is widely employed to drive in proportion mode pressure independent control valves where electrical fail-safe is needed, controlling heating and cooling systems by means of BIS (Building Management System) or suitable room thermostat (managing and generating proportional signal 0-10V). Electrical connection is discussed in the following section


In order to choose the right adaptor, follow the scheme below:

- VA93L with adaptor OA7010 (included)
- VA93H with adaptor OA748X (included)

APPROVALS



ELECTRICAL CONNECTION



OPERATING STATUS INDICATION

The 24 V electromotive actuator VAM85 has a RB LED indicating its operating status as shown by the table below:

OFF		No power supply
RGB blinking		Not set
Green blinking		Moving to position
Green steady on		Position reached
Red blinking		Calibration cycle
Red fast blinking		Valve stem closing failure
Red steady on		4/20 mA or 2/10 Vdc lost
Blue blinking		Supercapacitor acting. Fail-safe on
Blue fast blinking		End-of-life supercapacitor. Actuator replacement is suggested
Blue steady on		Supercapacitor charging

INSTALLATION




Fig.1




Fig.2




Fig.3

For electrical safety reasons the VAM85 electromotive actuator has to be installed as shown by pictures 1 and 2. Please avoid any upside down installation as suggested by the picture 3. When assembling the actuator from the valve, make sure the actuator stem is fully retracted and the fail-safe setting does not close the actuator when the power goes off (Electrical Fail-Safe Up or sitting "safe unmounting").

Do not power the actuator if not installed on the valve- Tighten the connecting ring by hand only


Keep 15 cm clear over the actuator to access it, if required

SETTING


The actuator can be set only through the specific configurator OC7484 (not included). The encoder is powered by 3 Alkaline batteries AA (not included). Please verify that the actuator is not powered during the setting procedure. Setting options are listed in the table below: default setting is written in bold.

	Voltage	Current
Y (+) - Analog input	0-10 VDC - default 2-10 VDC 0-5 VDC 5-10 VDC	0-20 mA 4-20 mA
Action	Direct Action (DA)	Reverse Action (RA) - default
Curve	Linear (LIN) - default	Equal percentage (Eq%)
Electrical fail-safe	Electrical Fail-Safe Down (EFSU) - default	Electrical Fail-Safe Up (EFSU)

Actuator action according to digital input is detailed below




Direct Action DA - when the signal increases, the valve closes.
0V valve open, 10 V valve closed



Reverse Action RA - when the signal increases, the valve opens. 0 V valve closed, 10 V valve open. It is suitable for VANTEC valves

Follow the procedure below to change actuator settings





Change Settings

Switching on the encoder

Connect the encoder to the dedicated port into the actuator and press the button for 2 sec.

The device switches off in few seconds if not connectd to the actuator. The actuator LED switches on.

The encoder has:


- A. LED status
- B. Display
- C. Button

Configuration

Use the knob to browse the encoder menu. Rotate clockwise to go ahead and counter-clockwise to go back. Keep pressed 2 sec to select and 4 sec to go back to previous level.

First level has following options:

- 1- Load Configuration: it shows on the display last configuration set of actuator ACTUATOR PARAMETER) and the current settings of the encoder PRESET PARAMETER).
- 2 - Set Configuration: it shows all the selectable settings
- 3- Safe Unmounting: select this option to safely unmount the actuator. The stem will fully retract.



Configuration procedure

Select a specific setting to see all the available options. One selected a setting, the encoder automatically goes back to the setting list. To go back the list avoiding any modification of the selected setting, press the button for 4 sec.

Settings are:

1. Control signal type

- I. Voltage
- II. Current

2. Control signal span

- a. 0-10 V (if setting 1 is "Voltage")
- b. 2-10 V (if setting 1 is "Voltage")
- c. 0-5 V (if setting 1 is "Voltage")
- d. 5-10 V (if setting 1 is "Voltage")
- e. 0-20 mA (if setting 1 is "Current")
- f. mA (if setting 1 is "Current")

3. Action type

- a. DA (Direct Action)
- b. RA (Reverse Action)

4. Curve type

- a. Linear
- b. Equal Percentage

5. Fail Safe action

- a. Electrical Fail Safe Up
- b. Electrical Fail Safe Down

To upload on the actuator the changes, go back to SET CONFIG and hold down for 5 sec.; DOWNLOAD PARAMETERS will appear and, upon completion of the upload ACTUATOR UPDATED. The status LED will light up green. The new parameters are saved at the same time into the en-coder: to modify other actuators with the same parameters, connect the configurator, move to SET CONFIG and hold down for 5 sec. until DOWNLOAD PARAMETERS and ACTUATOR UPDATED appear.

Safe Unmounting

Select this option to unmount the actuator if the electrical fail safe option is set on Down. Select the setting from the first level of the menu. Do not unmount the actuator on EFSD mode for the valve before having done the above procedure.



Vantec Item Code	Description	Adaptor included
VA813VL	Hydraulic kit - 1/2" 150L/H	0A7010
VA813L	Hydraulic kit - 1/2" 450L/H	0A7010
VA813H	Hydraulic kit - 1/2" 850L/H	0A7010
VA813L	Hydraulic kit - 3/4" 1000L/H	0A7010
VA813H	Hydraulic kit - 3/4" 1850L/H	0A7010
VA813L	Hydraulic kit - 1" X 3/4" X 2500 L/H	0A748X
VA813H	Hydraulic kit - 1" X 3/4" X 3300 L/H	0A748X
VA93VL	PICV 1/2" FxF 150L/H	0A7010
VA93L	PICV 1/2" FxF 450L/H	0A7010
VA93H	PICV 1/2" FxF 850L/H	0A7010
VA93L	PICV 3/4" FxF 1000L/H	0A7010
VA93H	PICV 3/4" FxF 1850L/H	0A7010
VA93L	PICV 1" FxF 2500L/H	0A748X
VA93H	PICV 1" FxF 3300L/H	0A748X
VA93H	PICV 1 1/4" FxF 5200L/H	0A748X

